



EXCAVATOR GEARS

An excavator swing gear must handle a complex load range that covers various combinations of thrust, radial and tilting loads. Prevent failure by conducting regular inspections and maintenance of the swing gear, pinion gear and bearings.

| Part No. | Description | Application |
|----------|-------------------------|--|
| 1141414 | GEAR GP-BR | 215, 320B, 320BL |
| 2003645 | GEAR GP-BR | 345B |
| 2276081 | GEAR GR - SWING BEARING | 320C, 320D, 320CL |
| 2276082 | GEAR GP-BR | 320C, 320D, 323D |
| 2276087 | GEAR GR - SWING BEARING | 325C, 225D |
| 2276089 | GEAR GR - SWING BEARING | 330C, 330C L, 330D, 330D L, 336D, 336D L |
| 2276094 | GEAR GP-BR | 345BII |
| 2291077 | GEAR GP-BR | 312C, 312CL |
| 2316854 | GEAR GR - SWING BEARING | 325B |
| 5C0451 | GEAR GR - SWING BEARING | 215, 215B |
| 7Y0745 | GEAR GR - SWING BEARING | 325, 325L |
| 7Y1563 | GEAR GP - SWING BEARING | 320L, 320N |
| 7Y1565 | GEAR GP - SWING BEARING | 320, 320L, 320N |
| 8K4127 | GEAR GR - SWING BEARING | 225, 225D, 229 |

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.